



## WATER DROPS

Step 1. Follow Best Demonstrated Practices for the type of substrate you are working on to provide a high quality undercoat system.

**This effect works best when done over light colors.**

Step 2. Mix Basecoat color at a ratio of 1 to 1 with the appropriate PCS Advanced Integrated Stabilizer for your spraying conditions. Apply 2 to 3 coats or until hiding is achieved.

Allow Basecoat Color to dry 30 minutes.

Step 3. With a Squirt Bottle of water, lightly mist surface. Squirting water up and letting the droplets "rain down" on the surface will create a more random appearance.

Step 4. With an airbrush, Spray lightly at a low angle, with white, from one direction. Change your color to black and spray using the same technique from the opposite direction. You want to lightly coat the water droplets.

Step 5. Allow water to evaporate, you may bake dry. DO NOT BLOW DRY or otherwise touch the surface.

Step 6. After water has evaporated, Clearcoat using any Ultra clearcoat. DO NOT TACK OFF THE PANEL WITH A TACK RAG! You will remove your effect.

