

Drying Schedule

E2B500 Black Conductive Primer must be flashed for 5-10 minutes and baked for 30 minutes at a minimum part temperature of 180°F to achieve maximum properties.

Post Cure Processing

E2B500 Black Conductive Primer sands easily using 320/400 grit paper.

P R O D U C T D A T A

To learn more about Sherwin-Williams Automotive products, visit our Web site at www.sherwin-automotive.com.